

CITY COLLECTION

Battery Heated Hand Warmer User's Guide



Step 1: Fully Charge the Battery Plug the adaptor into the wall and connect the battery. The **Red** light on the adaptor indicates that the battery is charging. The **Green** light indicates that the battery is charged.

Step 2: Power On

On the back of the hand warmer, locate the Velcro pocket and find the plug inside. Connect the plug to the battery. Place the battery inside of the pocket, and Velcro the pocket closed. When the battery is connected, the heat is powered on. Heat will be powered for up to 2.5 hours. (*Heating time may vary based on the condition of the battery.)

Step 3: Power Off To turn off the heat, simply unplug the connection to the battery.

Storage Tips Store in a cool dry place. Fully charge the battery before each use. Fully charge the battery prior to storing and at least once every 6 months of storage thereafter.

Wash and Care Remove the battery from the garment prior to washing. Hand wash in cold water only. Hang dry. Do not iron. Do not use bleach or cleaning solvents. Do not twist or wring. Do not turn power on when garment is folded.

Warning Avoid direct contact with all liquids. Never tamper with connection or use other power source.

Helpful Reminders

Do not apply the garments to sensitive skin areas, acute injuries, and open wounds. This garment is not recommended for use by children, pregnant women, and immobile individuals with disabilities. In the unlikely occurrence of skin discomfort and irritation, immediately discontinue the use of the product and consult your physician and health care professional.

PRODUCT QUESTIONS? Email: Service@VentureHeat.com
For instructional videos on the products, please visit our YouTube channel by scanning the bar code with your smart phone or type in:
www.youtube.com/VentureHeat



To stay current on new product info and promotions, "LIKE" us on FACEBOOK
<https://www.facebook.com/VentureHeatFans>