



12V Touring Edition Heated Gloves User's Guide

Step 1: Access the Battery With the vehicle powered off, access the 12V battery by following the instructions in the vehicle's owners manual.

Step 2: Connect the Battery Harness Connect the battery harness to the terminals of the battery by removing the attachment screws. Attach the red ring of the battery harness to the positive terminal and black ring to the negative terminal. An SAE adapter can also be purchased to use with an existing battery tender.

Tuck the remaining wires under the seat, leaving at least a couple of inches from the plug extending from the body of the vehicle. The location and manner in which this is done will vary depending on the configuration of the vehicle. Return any vehicle body panels or equipment to their original location.

Step 3: Connect the Gloves The gloves can be worn on their own using the included Y-splitter cable or connected to VentureHeat's 12V Heated Jacket Liner. The 12V Heated Jacket Liner is pre-wired with glove connectors so only one battery harness is needed, though you will still be able to control the temperature on the gloves and jacket separately.

Step 5: Power On To turn on the power, press and hold the power button on the top of the glove for two seconds until the control panel lights up in red.

Step 6: Adjust the Temperature Click the button on top of the glove to change the temperature settings Red is High heat. Yellow is Medium heat. Green is Low heat.

Step 5: Power Off Press & hold the power button on the top of the glove for 2 seconds until all of the lights turn off.

Wash and Care Hand wash in cold water only. Hang dry. Do not iron. Do not use bleach or cleaning solvents. Do not twist or wring. Do not turn power on when garment is folded. Store in a cool dry place.

Warning Avoid direct contact with all liquids. Never tamper with connection or use other power source.

Helpful Reminders

Do not apply the garment to sensitive skin areas, acute injuries, and open wounds. This garment is not recommended for use by children, pregnant women, and immobile individuals with disabilities. In the unlikely occurrence of skin discomfort and irritation, immediately discontinue the use of the product; consult your physician and health care professional. Product may not be returned once opened & used.

PRODUCT QUESTIONS? Email: Service@VentureHeat.com

For instructional videos on the products, please visit our YouTube channel by scanning the bar code with your smart phone or type in:
www.youtube.com/VentureHeat



To stay current on new product info and promotions, "LIKE" us on FACEBOOK
<https://www.facebook.com/VentureHeatFans>